


Course Agenda

- 1. Who is Somfy?
- 2. What is Integration?
- 3. How to Integrate?
- 4. When to Integrate?
- 5. Somfy Interfaces
 - myLink
 - UAI Plus
 - Specialty Interfaces
- 6. animeo IP
- 7. Integrating with Lutron



Who is Somfy?



Who is Somfy Somfy Organization





of experience in motorization

60 Countries

121 Subsidiaries

8,940 Employees

2,066 Patents in Somfy portfolio

Production capacity 20,000,000
motors produced

100+ million
radio motors sold
worldwide

Production capacity 20,000,000
motors per year

270+ million
users worldwide

8 manufacturing plants

Over 2 million

connected devices





Who is Somfy North American Locations



150 EMPLOYEES

4 TRAINING CENTERS



CUSTOMER SERVICE


8 am to 8 pm EST





Who is Somfy What Does Somfy Offer?


The widest range of strong, quiet motors and variety of controls for all types of applications and technologies







Who is Somfy Somfy Evolution Fueled by Constant Innovation






What is Integration?



What is Integration Defining Integration




Two (or more) unlike systems to communicate with each other


















Somfy's system connects to almost everything!





How to Integrate?



How to Integrate *Understanding Power*



There are several flexible ways to provide power to a motor



Battery operated motor (primary batteries or batteries)

Benefits

- No electrical power connection required:
- No electrician required for installation
- No wiring costs
- No visual impact
- Recommended for renovation projects and/or locations where there is no mains power supply available nearby.

Limitations

- Battery-operated motors can only be used to motorize small blinds
- Batteries require changing (the battery life can be extended through the use of solar panels)



AC power (connects directly to the mains power)

Benefits

- Can be used to motorize large curtains, blinds and projection screens
- No additional accessories (transformers) required
- Easy alignment in installations containing several blinds (the AC current is constant): the blinds move up and down simultaneously
- No maintenance required for the entire product lifetime

Limitations

- An electrician is required for installation
- Takes up more space than DC/ battery-operated motors
- A mains power supply is required for renovation projects



DC power (connects to the mains power via a transformer)

Benefits

- . Small, economical and easy to integrate
- No electrician required for installation
- Regulated speed (according to motor)
- . No maintenance required for the entire product lifetime

Limitations

- . Cannot be used to motorize large or heavy blinds
- A transformer is required to convert AC current to DC current





How to Integrate Integrating with Somfy

















How to Integrate What Can be Motorized



Any application Inside and out



Silhouette® & Vignettes®



Horizontal Blinds



Sheer/Layered Shades



Skylights



Roman/Woven Shades

Awnings



Roller/Solar Shades



Draperies



Rolling Shutters



Exterior Screens



Projection Screens



Cellular/Pleated Shades



Pergolas






How to Integrate Integrating with Somfy Features



Somfy-powered solutions feature FLEXIBLE CONTROL





When to Integrate?



When to Integrate Types of Integration





Scenes



Voice control



Conference rooms



Home theater



Connected home devices



Building Management Systems





When to Integrate *Technologies*



Dry contact – Simple contact closures manage trigger keypad button presses



animeo IP - DecoFlex Keypad for animeo IP SDN – DecoFlex Keypad for standalone SDN RTS – Dry Contact to RTS Interface Motors – Direct control over select motors **IP** – High speed data over a computer network



SDN animeo[®] IP – HTTP Web API Somfy myLink™– IP Somfy Synergy Somfy Connect™ UAI Plus – IP Somfy Synergy

RS232 – Serial Communication to a single or multiple devices



SDN – Two way communication through an RS485 connection RTS – One way communication through an URTSI

Gateway/Translators – A bridge providing two-way communication between third-party systems and Somfy product family



SDN Power Over Ethernet (POE) Gateway Somfy Connect™ LTI Somfy Connect™ BMS Interface





When to Integrate Integration Systems











Stand Alone SDN systems can directly interact with Lighting or Shading systems via a Somfy Connect LTI or SDN 0-10V Interface, enabling lighting controls to operate Somfy Motors

Building Management Systems (BMS)





Utilizing the Somfy Connect BMS, SDN and animeo IP systems are able to send and receive data points on a BACnet system

Automation Control Systems







Through RS232, IP, or Dry Contact automation systems can be programmed to directly interact with SDN and animeo IP systems





Somfy Interfaces



Somfy Interfaces *Products*



- Individual Group Control (IGC) 4n1 Motor Controller
- Somfy myLink™
- Z-Wave to RTS Interface (ZRTSI)
- Universal RTS Interface (URTSI)
- Somfy Connect™ UAI Plus
- Somfy Connect™ LTI
- Somfy Connect™ BMS Interface
- SDN Power over Ethernet (PoE) Gateway
- SDN 0-10V Interface
- DecoFlex Digital Keypads
- animeo[®] IP







Somfy Interfaces
myLink™



Somfy Interfaces myLink™ – Technology Review



• RTS is omnidirectional; One way



UP



Maximum range of 65' in optimal conditions



MY/ STOP



• "my" feature offers 1 intermediate position



DOWN



Motors can be controlled by up to 12 programmable devices







• Mix and match controls (handheld remotes, wall switches, timers, etc.)







Somfy Interfaces *myLink™ – Technology Review*



- When wires cannot be run to the window (battery solution)
- Exterior application control (AC motors).
 - All Somfy exterior motors are rated for outdoor use

Lower cost solution than traditional hard-wired motors

- Small window applications
- Multiple control options available



































Somfy Interfaces myLink™ – Features



- Control for up to 16 RTS channels per myLink™ from iOS and Android devices
- Join up to 10 myLinks together for multi-zone control
- Manually activate RTS products
- Automate window coverings with scenes and schedules
- Supports Up/Down/My/Stop commands and incremental control (tilt/brightness)
- Multiple users
- Remote access
- Integration with third-party systems over IP
- Compatible with Somfy Synergy™ API
- Compatible with Amazon Alexa



myLink RTS Smartphone and Tablet Interface (1811403)





Somfy Interfaces myLink™ – Functions



	ELEMENT	FUNCTION
	Setup Button	Engages setup mode
2	Status LED	Solid Red: Setup mode. The myLink is ready to accept WiFi network information or have its PIN changed. This is the mode the myLink should be in out of the box. Solid Green: myLink is successfully connected to a WiFi network Slow Blinking Green: myLink is trying to connect to a WiFi network/is disconnected from its known WiFi network Single Orange Blink: myLink is sending RTS commands Solid Orange: Firmware update mode Slow Blinking Red: myLink is scanning both 2.4GHz and 5GHz bands for nearby WiFi networks
3	AC Prongs	AC prongs








Somfy Interfaces *myLink™*










Somfy Interfaces *myLink™*









Somfy Interfaces myLink™ – Plug & Play Smarthome Control



REMOTE

Control your shades anytime / anywhere




SCENE

Group shades & trigger them to a desired position



SCHEDULE

Timed events or Sunset /Sunrise







Somfy Interfaces myLink™ – Plug & Play Smarthome Control



Easy to Program



- Only software required is the app
- Visual prompts and walkthroughs
 - Initial setup wizard
 - RTS programming wizard

Easy to add users




- Share access with multiple users/devices using 4 digit PIN
- App generates email with step by step instructions





Somfy Interfaces myLink™ – Plug & Play Smarthome Control






Building a Smart Home with Somfy





Somfy Interfaces myLink™ — Plug & Play Smarthome Control









Somfy Interfaces myLink™ – System Requirements




WIRELESS ROUTER

- 2.4GHz & 5Ghz networks with WEP, WPA2, TKIP, open and mixed mode encryption
- IOS DEVICE RUNNING IOS 8 OR HIGHER OR ANDROID DEVICE RUNNING JELLYBEAN OR HIGHER
- RADIO TECHNOLOGY SOMFY® MOTORIZED PRODUCTS
 - All RTS motor limits are set (including the MY position if desired)
 - There is a preprogrammed RTS control (handheld, in-wall or table top) that controls the motors that will also be controlled by the myLink
 - Individual channels on transmitter to create groups on myLink











Somfy Interfaces *myLink™ – Installation Checklist*



Use	this checklist (system requirements) to ensure myLink™ will perform as designed.
[Radio Technology Somfy® (RTS) products programmed with limits and "my" position set, and an
	RTS control device (Telis, Decoflex or similar).
[☐ A wireless router running 2.4 or 5 GHz networks with WEP, WPA2, open and mixed mode encryption
[☐ Healthy, robust WiFi network (without WiFi extenders)
	Note: Internet only required for remote access
[□ A mobile device running iOS 7 or higher, or an Android™ device running Jellybean or higher
[□ 110V outlet available
[☐ For indoor use only
The	myLink is a WIFI to RTS interface and requires the same RTS environmental
con	siderations for optimal performance:
	☐ Must be within a range of up to 35 ft. from window covering featuring RTS
	☐ Motor antenna accessible
[□ Designed as a room/zone controller
[☐ Environmental factors such as steel or concrete may affect RTS signals.
[☐ Areas in close proximity can cause interference.





Somfy Interfaces *myLink™ – Installation Checklist*



Is the Wi-Fi network stable and reliable?

- Do not use Wi-Fi extenders!!
- Use Mesh Networks to improve Wi-Fi signal

Are you aware of any higher-level network settings such as:

- Restricted by MAC/IP address?
- Subnets?
- Blocked ports?
- Blocking of UDP broadcasts?







Somfy Interfaces myLink™ – Best Practices



Range to motors

- Within 25-35FT or Room Control
- Do Not USE!!!! RTS Repeater
 - Creates overlapping signals
 - Add another myLink instead

When to choose 2.4ghz or 5gHz Wi-Fi network?

- 2.4Ghz = longer distance, slower speeds
- 5Ghz = shorter distance, faster speeds

Check the Wi-Fi strength at the spot you want to install your myLink system.

- Setup a myLink at the spot you want to install your myLink
- Go to the Info page, and select the myLink.
 - View Wi-Fi Signal Strength information
 - If signal is listed as Poor you will need to find a new location, or improve the Wi-Fi signal strength
- Poor Signal strength means a poor connection for myLink

AVOID PLACEMENT NEAR HIGH INTERFERENCE AREAS

Racks, microwaves, RF equipment, lots of metal/concrete

COME PREPARED WITH YOUR OWN WIFI NETWORK

 Bring standalone router to prove myLink performance when site's network has issues

	Info
	Living Room
	Hardware
ID:	CC100441
Base Address:	004710
MAC Address:	28:24:FF:29:19:2
Firmware Version:	4.92
System Time:	Tue, Feb 20, 07:48 PN
	Network
Network:	Amazon Demo
Wifi Signal Strength:	Excellent (54
IP Address:	192.168.9.58
	Get Device Logs
	Get Device Logs





Somfy Interfaces myLink™ – LED Indicators



Indicates network connection status and RTS command transmission

- Blinking red to solid red:
 - Scanning for Wi-Fi networks. Blinking stops when scan complete
 - Re-engage by pressing setup button
- Solid Green: connected to LAN
- Slow Blinking Green: myLink is trying to connect to a Wi-Fi network/is disconnected from its known Wi-Fi network
- Quick Red Flash: sending RTS command
- Solid Amber: firmware update mode









3.



4.



5.







Somfy Interfaces myLink™ – Driver Availability



Integrates with

- Control 4
- Crestron
- Savant
- RTI
- URC Universal Remote Control
- Elan
















Somfy Interfaces myLink™ – Driver Availability










Somfy Interfaces myLink™ – Driver Availability










Somfy Interfaces myLink™ – Integrating with Control4



Key Integration Points

Setting System ID – This is an added security measure to ensure the myLink can speak with the automation system. The system ID can be just about anything you want. Usually a birthday, street address or the end users last name will work just fine. This must be set in the myLink app.

The Somfy myLink also supports Simple Device Discovery Protocol (SDDP). This allows for the myLink to be discovered by a Control4 system when it is on the IP network.



Use the slider to enable or disable Control4's Simple Device Discovery Protocol. This will not affect operation of the Somfy myLink app.

SDDP






Somfy Interfaces *myLink™ – Integrating with Control4*



Key Integration Points

Integration Report – The integration report contains all of the necessary channel addresses, scenes, scene identifications, system id and the IP Address needed to integrate the myLink into 3rd party control systems. This can be printed or emailed.

This report can be found in the integration section of the myLink app menu.
























Smart Speaker Use Case Frequency January 2018


Smart Speaker Use Case Frequency - January 2019







U.S. Adult Smart Speaker Installed Base - January 2019







Connected journey for every consumer, every need at any budget






















Third party integration























NEW SMART HOME mYLINK ECOSYSTEM

amazon alexa

ROUTINES












myLink: Alexa Smart Home Skill

You can now activate your shades in combination with other devices through voice control (Lights, Thermostats etc.)

"Alexa, Good Morning"

"Alexa, Good Night"













myLink: Alexa Smart Home Skill









How to Create a routine in the Amazon Alexa app








myLink Smart Shading even easier

Alexa Routines series



 How to connect myLink to Amazon Alexa -Routines quick start



2. How to create a routine in the Alexa App

"How to" videos



3. How to edit or delete a routine in the Alexa App







mylink: IFTTT and Google Home

You can now activate your shades in combination with other devices through IFTTT and voice control (Lights, Thermostats, etc)

"Hey Google, Welcome Home"

"Hey Google, Good night"









• IF THIS...

















• THEN...

THAT...






and Google Home



















mylink: IFTTT and Google Home



Download the IFTTT app and create an account











Somfy Interfaces

Somfy Connect™ Universal Automation Interface Plus



Somfy Interfaces Somfy Connect™ UAI Plus - Features



- SDN commission and integrate over IP/Wi-Fi
 - Onboard serial pot for integration only, not commissioning
- Setup wizard for commissioning (programming)
- Common names for grouping
- Drag and drop grouping into a table
- Embedded programming software (Google Chrome required)
- Easily discovered using the "Network" tab in your Windows PC file folder
- Programming is password protected
- Firmware update over network with internet access
- 250 motor limit
- Only 1 installer needed to program SDN
 - No need for a second "runner" while programming
- Integration report that can be printed or email



Somfy Connect Universal Automation Interface Plus (1870272)






Somfy Interfaces Somfy Connect™ UAI Plus - Functions



	ELEMENT	FUNCTION
1	External Power input	12-24V DC power supply
2	Ethernet Port	Ethernet input
3	Port 0	N/A
4	Port 1	RS-232 Input/SDN Bus Power input
5	Port 2	SDN connection







Somfy Interfaces Somfy Connect™ UAI Plus - Comparison



	SDN PC Programming	UAI Plus
Serial Port for Programming	✓	
USB converter	✓	
Group Setting	✓	✓
Set and adjust limits	✓	✓
Auto Discovery	✓	✓
PC Programming	✓	✓
Easy Group design		✓
Integration Report		✓
WiFi Connectivity		✓
1 programmer for setting the motors		~
Drag and Drop grouping		✓
Embedded programming Software		✓
Updates via IP		✓





Somfy Interfaces Somfy Connect™ UAI Plus – Driver Availability



Integrates with

- Control 4
- Crestron
- Savant
- RTI
- URC Universal Remote Control
- Elan
- Lutron
















Somfy Interfaces Somfy Connect™ UAI Plus










Somfy Interfaces Somfy Connect™ UAI Plus – Driver Location










Somfy Interfaces Somfy Connect™ UAI Plus – Driver Location









Specialty Interfaces



Somfy Interfaces Specialty Interfaces - URTSI



- 16 channels of RTS control per URTSI communicates with:
 - RS232
 - RS485
 - IR
- Using RS485
 - Control up to 16 URTSI II's together
- 256 channels in a system
 - Cascade up to 16 URTSI IIs with Cat 5e or better
 - Power up to 16 URTSI IIs with one power supply in a system (alternate power supply sold separately by outside vendor)
- L: 3" x W: 4" x H: 1.75"



Universal RTS Interface (1810872)







Somfy Interfaces Specialty Interfaces - URTSI



	ELEMENT	FUNCTION	
1	Up Button	RTS (Test) Up directional button	
2	Stop Button	RTS (Test) Stop directional button	
3	Down Button	RTS (Test) Down directional button	
4	Programming Button	RTS Programming button	
5	Rotary Dial	Programming: RTS Channel selector	
		Operation: URTSI Address selector (RS485) $(A-0 = CH 10-16)$	
6	Bi-Color LED	Green = Power; Red Flash = RTS Transmission	

	ELEMENT	FUNCTION
7	Antenna	RTS antenna
8	IR Sensor Input	RJ9 port for Somfy's IR receiver (9015078)
9	RS232 or RS485 Input	RJ45 for RS232 or RS485 serial input
10	.0 RS485 Expansion RJ45 for RS485 expansion	
11	1 Power 3.5mm jack for included power supply	
		(9V DC 200mA)









Somfy Interfaces Specialty Interfaces - URTSI



When should I use the URTSI?

- When you must use serial
- When you need to integrate RTS motors into Lutron (see later slides)
- When needing to use IR (Somfy IR Receiver required)
 - There have been reported issues with making your own IR cable





Somfy Interfaces Specialty Interfaces - ZRTSI



- Network Wide Inclusion
- Z-Wave Development Kit 4.54.03 (Bridge Controller Library 3.42)
- Z-Wave 300 series chip
- Easy to navigate LCD menu
- 16 Channels of RTS
- Repeating node within the Z-Wave network
- Plugs into any standard 120V AC outlet





Z-Wave to RTS Interface (1810872)






Somfy Interfaces Specialty Interfaces - ZRTSI





	ELEMENT	FUNCTION	
1	LCD Screen	Navigation Menu	
2	S Indicator	Fashes when RTS Transmits	
3	Z Indicator	Stays On when connected to a Z-Wave Network	
4	Left Arrow	Navigates Menu Left	
5	Select Button	Selection Button for Menu	
6	Right Arrow	Navigates Menu Right	

	ELEMENT	FUNCTION
7	AC Prongs	AC Prongs
8	Support	Wall Supports when plugged into an outlet







Somfy Interfaces Specialty Interfaces - ZRTSI



Integrating:

- Z-Wave Certified Product
 - This device will work with other Z-Wave certified controllers with On (up) and Off (down) commands. Stop command may be missing.
- Does not support stop on reverse
- Supported Controller (With Stop)
 - Nexia
 - Vera
 - Iris
 - Homeseer
- Supported Controllers (Without Stop)
 - Smart Things
 - Wink
 - Fibaro
 - Logitech









Somfy Interfaces Specialty Interfaces — RTS Dry Contact Interface



- The RTS Dry Contact Interface can be used to communicate between home automation or other third party systems and SOMFY's RTS products.
- Need at least 2 dry contact ports
 - 1 for UP
 - 1 for Down
 - Closing both will issue a STOP
- Momentary contact closure (Normally Open or Normally Closed 0.5 – 1 sec closure times)
- Battery operated
- 1 Single Channel of RTS







Somfy Interfaces Specialty Interfaces — RTS Dry Contact Interface




MECHANICAL SPECIFICATIONS

ELECTRICAL SPECIFICATIONS

Overall Dimensions: L: 6 in. W: 4 ¼ in. D: 2 ¼ in. Power: 3v Lithium battery CR2430

Typical Range (Optimal Conditions): 65 ft. Frequency: 433.42 Mhz

OPERATING INSTRUCTIONS



- 1. Place the RTS compatible motor or control in programming mode as described in the individual product operating instructions.
- 2. Press the programming button on the RTS Interface to program it in the memory of the RTS motor or control.
- 3. To activate an UP command, a momentary contact (relay) closure is required between the WHITE and GREEN wires.
- 4. To activate a DOWN command, a contact closure is required between the BLACK and GREEN wires.
- 5. To activate a STOP command or Intermediate Position, a contact closure is required between the RED and GREEN wires.





Somfy Interfaces Specialty Interfaces — Wired Technology



- When choosing Wired control units, power supply and wiring should be planned prior to construction and include the possibilities of future renovations.
- Manual controls must be located near windows and in strategic areas which often requires a detailed system design process before development could take place.

System Features:

- Provides control of motorized window coverings via a line voltage or low voltage wall switch wired directly to a standard motor
- Offers control using common line voltage switching
- Requires an electrician for line voltage switches
- Wall switches provide single or group motor control
- A separate switch is required for each motorized window covering





Somfy Interfaces Specialty Interfaces — IGC 4N1 Motor Controller



- Control up to four WT motors individually or in groups
- Provides default intermediate positions of 25%, 50% and 75%
 openness which can also be customized for each motor
- Individual control and Master control using DecoFlex Dry

Contact Keypads

- Four Keypad ports and two Master ports
- CSA/UL certified E160923
- Plenum rated





Individual Group Control (IGC) 4N1 Motor Controller (1811416)






Somfy Interfaces Specialty Interfaces — IGC 4N1 Motor Controller



	ELEMENT	FUNCTION
1	Power LED	Indicates power is on
2	Motor Selector Button	Sets Keypad group
3	Dip Switches	Motor selection
4	Master Ports	Connect Master Keypads and Daisy Chain Controllers
5	Individual Motor Key Ports	Connect Keypads for each group
6	To 110V AC	Connect to power
7	Program Button	Set intermediate positions
8	To Motors	Connect to motors








Somfy Interfaces Specialty Interfaces — IGC 4N1 Motor Controller









Somfy Interfaces Specialty Interfaces — Integrating with SDN



- 2-way hardwire motor control
- Bus segments
 - 255 Devices
 - 4000 ft. total cumulative length
- Group programming allows for multiple motors to move at the same time
- Percentage positions
- Bus line devices for easy connection
- Freedom of wiring







6 button

8 button










Somfy Interfaces Specialty Interfaces — Integrating with SDN



- Hardwired solution a must
- Positional feedback from the motor is needed
- Building or residence already wired
- Multiple control options available













Somfy Interfaces Specialty Interfaces — SDN DecoFlex Digital Keypad



- In-wall control with plug-in connections
- 6 button and 8 button configurations
- Dry contact third party integration
- Custom engravable buttons
- Fits into any Decora wall plate
- Powered and communicates over single wire
- Available in White*, Black, & Ivory

PRESET 1
PRESET 2
PRESET 3





8 button

SDN DecoFlex Digital Keypad 6-Button White 1811252 (shown)
SDN DecoFlex Digital Keypad 8-Button White 1811253 (shown)
SDN DecoFlex Digital Keypad with Group Function 6-Button 1811749
SDN DecoFlex Digital Keypad with Group Function 8-Button 1811750




^{*}Part number show for white version only




Somfy Interfaces Specialty Interfaces — SDN DecoFlex Digital Keypad



	ELEMENT	FUNCTION
1	Buttons	Press for motor control. Can be programmed with functions for Press, Release, Hold and Sequential
2	Front LEDs	Group selection Amber - Solid in SDN mode and flashes in group mode
3	Dry Contact Inputs	Triggers programmed button function
4	Power LED	Blinking Red - SDN power
5	SDN Connection	Power and data connection to SDN bus



Detail of Inputs









Somfy Interfaces Specialty Interfaces — SDN DecoFlex Digital Keypad



- 8 Contacts to provide control of each button
- A basic level of integration supported by almost all control systems
- Actions determined by keypad programming
- One relay required per button contact











8 button






Somfy Interfaces Specialty Interfaces — 0-10V Interface (11 Position)



The 0-10V Interface is a Somfy Digital Network™ (SDN) device which receives lighting industry standard 0-10V control input to operate SDN RS485 motors.

- Interface for controlling Somfy Digital motors through 0-10V Input
- 0-10V is a standard type of control for many Lighting companies (Eaton, Acuity, Leviton, etc)
- Grouping up to 20 motors (4 Data Hubs) per interface



0-10V Interface (11 Position) (1870489)








Somfy Interfaces Specialty Interfaces — 0-10V Interface (11 Position)



	ELEMENT	FUNCTION
1	Reverse Button	Reverse shade position percentage
2	Power Input (5.5 mm Female Barrel Connector)	Supply 24V DC power to device
3	0-10V Input (screw clamp connector)	Input from Control System
4	SDN Bus Power and Data Output (Female RJ45)	Output for bus data and power

LED Indicators							
LABEL	LABEL ELEMENT COLOR FUNCTION ON FUNCTION OFF						
Р	Bus Power	Green	Power	No Power			
Α	A (activity)	Green	Data	No Data			










Somfy Interfaces Specialty Interfaces — 0-10V Interface (11 Position)









- System control
 - Stand-alone SDN control individual or motor groups position (%) – feedback on motors only
 - Position (absolute) feedback on motors only
 - Intermediate position
 - Up, Stop, and Down control
 - animeo® IP control individual or motor groups, sensors, and virtual keypads
 - Position (%) feedback on motors only
 - Up, Stop, and Down control/commands
 - Priority control
 - Sensor data provides single direction information to BMS system
 - Supports up to 1500 data points
 - Integration capabilities:
 - Modbus
 - BACnet MS/TP
 - BACnet IP
- Programmable through user friendly interface
- Auto discovery for animeo IP




Somfy ConnectTM BMS Interface (1870249)












TAG	ELEMENT
SPI	Not used
RUI	Once powered, wait 20 seconds and the green LED will begin to flash to indicate normal operation.
ERI	A solid red light indicates a system error on the interface.
RX	Blinks yellow to indicate activity
TX	Blinks red to indicate activity
PW	Solid green at all times
RT	Unused

	ELEMENT	FUNCTION
1	Field	BACnet MS/TP and Modbus connection screw terminal
2	Ethernet Local area network configuration or using an RJ45 connection port	
3	Host	Stand-alone SDN connection screw terminal
4	Power	9-30V DC or 12-24V AC screw terminal
5	Dip Switches	Change configuration options


























Power over Ethernet (PoE) distributes network signals and electrical power to transmit communication over standard low-voltage category cabling to various endpoints, including shades, draperies, LED lighting, HVAC controls, cameras and other networked devices in new or existing projects.





Savings up to on infrastructure cost & service for shading!



Cut costs:

Lower infrastructure costs and capital expenses by eliminating wall circuits for endpoints and consolidating continuous power supply systems.



Save time:

Shorten deployment time through reducing the stages of construction and installation.



Efficiency:

Simplifies the building code process for new construction or renovations.



Conserve energy:

Reduce energy expenditures using Cisco energy management systems.



Improve performance: Extend intelligent load-shedding capabilities to switch-connected devices.







- Compatible with Molex Transcend Control System, distributes power and data to shade and drapery motors IEEE 802.3bt and Cisco UPoE compliant device
- PoE switches must support LLDP
- Capable of powering a single or multiple motors compatible with third party control drivers
- Easy and secure convergence of IP infrastructure
- Easy to connect/disconnect; allow daisy-chain capability safe operation and industry-standard compliance (UL 2108/ UL 1310)
- Metal enclosure meets Plenum requirements



SDN Power over Ethernet Gateway (1860326)







	ELEMENT	FUNCTION
1	Ethernet Input	Power and Data Input from PoE system
2	SDN Output to motors	Power and Data output to Somfy 24V DC SDN RS485 motors

LED Indicators						
LABEL ELEMENT COLOR FUNCTION ON FUNCTION						
PWR	PWR Power		Powered	No Power		
ACT	Active Ethernet	Green	Ethernet Active	No Ethernet Activity		
LINK	Communication Link	Orange	Linked (Blinks)	Not Linked (not blinking)		









Power Over Ethernet:

For shades and draperies up to **4 motors** per interface (individual control only)

- Trend for POE infrastructure to power Buildings:
 - 1 wire for power and data
- Compatible with our 24v motors:
 - ST30 DC
 - ST50 DC
 - Irismo 35
- Control Methods: CoAP/Somfy Synergy API
- (Control 4 & other drivers to be developed)

	Sonesse® ULTRA 50 DC RS485	Sonesse® 30 RS485	Mini DC (w/RS485 Enclosure Kit)
Number of motors operating at a time	1	2	1
Group operation	Cascading individually	2 motors at a time	Not available: 1 motor per Gateway
Wattage per motor	36W	20W	48W








Gateway input pinout:

Supports both ANSI/TIA/EIA 568 A & B Standards

Gateway output cables:

- PoE Gateway to Motor Adapter (9025010)
 - Cable length: 13 in.
- PoE Gateway to Motor/animeo® Keypad Adapter (Plenum Rated) (9025011).
 - Cable length: 13 in. overall, 8 in. to keypad





30% Up Stop & 50% Down 70% **Eco-Mode** has been overridden in this zone. The "Eco-button will return this zone to automated functions.

animeo® IP



animeo® IP *Building Controller*



- Solar depth entrance management for dynamic facade control
- Sensor-threshold-based motor control
- Accurate time & astronomic motor control
- Network-based motor control with user account access
- Facility manager access to global system status & control
- Integration-ready for third party control systems and BMS systems
- System auto discovery of motors, sensors and keypads
- IP connectivity for Sub Controller connections, virtual keypads, remote access and programming
- System can be expanded with the addition of a Sub Controller



animeo IP Building Controller (1822314)







animeo® IP Building Controller



	ELEMENT	FUNCTION
1	SDN Bus	Connection to SDN Bus
2	Sensor Bus	Connection to SDN sensor bus
3	Service	USB connection for service
4	Alarm Input	N/C input allowing for system override from 3rd party controller
5	Key In	N/O input allowing for system override from 3rd party controller
6	Error Out	Digital output for notification of system failure 24V DC @ 1A (N/C or N/O)
7	animeo IP Network	10/100 mbps Internal network for connecting to Sub Controllers
8	External Network	10/100 mbps Network connection to LAN for virtual keypads and remote access
9	Status Indicator	Solid Green = initial system boot up Rapid Green/Red Flash saving configuration Green Flash* = system normal Red Flash = system has experienced an error *Speed of flash indicates system load
10	Power Input	100V AC – 240V AC switching power supply
11	Din-rail mounting pins	For din-rail mounting









animeo® IP DecoFlex Digital Keypads



- In-wall control with plug-in connections
- 6 button and 8 button configurations
- Dry contact third party integration
- Custom engravable buttons
- Fits into any Decora wall plate
- Powered and communicates over single cat5e (or better) cable
- Available in White*, Black, & Ivory





6 button

8 button

animeo IP DecoFlex Digital Keypad 6-Button White 1811288 animeo IP DecoFlex Digital Keypad 8-Button White 1811289







animeo® IP DecoFlex Digital Keypads



	ELEMENT	FUNCTION
1	Buttons	Press for motor control. Can be programmed with functions for Press, Release, Hold and Sequential
2	Front LEDs	Group selection Amber - Solid in SDN mode and flashes in group mode
3	Dry Contact Inputs	Triggers programmed button function
4	Power LED	Blinking Red - SDN power
5	SDN Connection	Power and data connection to SDN bus



Detail of Inputs







animeo® IP DecoFlex Digital Keypads





6-Button

- Single zone of control
- Button profiles
- Includes all necessary engraved buttons
- Included into the system with the one button keypad wizard
- Available in multiple colors:
 - White, Black, & Ivory



8-Button

6 BUTT	6 BUTTON KEYPAD CONFIGURATION OPTIONS							
	No Eco (default)		Eco Priority		Preset Priority			
Button 1	Move to 25%		Toggle Eco-Mode		Move to 25%			
Button 2	Move to 50%	* PRESET 1	Move to 40%	e ECO-MODE PRESET 1	Move to 50%	PRESET 1 PRESET 2		
Button 3	Move to 75%	PRESET 3	Move to 60%	PRESET 2	Move to 75%	PRESET 3		
Button 4	*Dry Contact Integration		*Dry Contact Integration		*Dry Contact Integration			
Button 5	*Dry Contact Integration		*Dry Contact Integration		*Dry Contact Integration			
Button 6	Stop	STOP	Stop	STOP	Toggle Eco-Mode	ECO-MODE		
Button 7	Move to Down Limit	V A	Move to Down Limit	V A	Move to Down Limit	V A		
Button 8	Move to Up Limit		Move to Up Limit		Move to Up Limit			

8 BUTTON KEYPAD CONFIGURATION OPTIONS							
	Preset Priority (default)		Eco Priority		No Eco		
Button 1	Move to 20%		Toggle Eco-Mode		Open	1	
Button 2	Move to 40%	PRESET 1	Move to 20%	ECO-MODE PRESET 1	Move to 20%	PRESET 1	
Button 3	Move to 60%	PRESET 2	Move to 40%	PRESET 2	Move to 40%	PRESET 2	
Button 4	Move to 80%	PRESET 4	Move to 60%	PRESET 3	Move to 60%	PRESET 3	
Button 5	Toggle Eco-Mode	ECO-MODE	Move to 80%	PRESET 4	Move to 80%	PRESET 4	
Button 6	Stop	STOP	Stop	STOP	Close	CLOSE	
Button 7	Move to Down Limit	V A	Move to Down Limit	V A	Move to Down Limit	▼ A	
Button 8	Move to Up Limit		Move to Up Limit		Move to Up Limit		






animeo® IP Virtual Keypads



- Web based access to animeo IP system
- Compatible with all devices (HTML5, CSS)
- Two way feedback
- User based login









Integrating with Stand Alone Lutron Systems




Integration with Lutron Lutron Systems



Lutron is a very popular lighting control system. There are some occasions in which their keypads need to control Somfy Motors. There are various Lutron systems currently on the market today:

- Homeworks QS
- Radio RA 2
- Radio RA Select
- Grafik Eye QS
- myRoom Plus





Morning

Entertain

Evening

· All On

· All Off

. Relax



Integration with Lutron *LTI*



- Support for RadioRA® 2, HomeWorks® QS, Quantum®, and GRAFIK Eye® QS systems
 - Able to interpret:
 - Button press
 - Button release
 - Button Hold
 - Toggle
 - Group Raise/Lower
- Hardware real-time clock for scheduled events
 - Astronomic events
 - Repeatable schedules
- 300 Programmable Lutron Home Control and communication maps
- 198 programmable timed events
- One Somfy Connect[™] LTI can power up to 4 URTSI IIs when using included power supply.



Somfy Connect LTI (1870210)






Integration with Lutron *LTI*



	ELEMENT	FUNCTION
1	SDN BUS	RS485 – Connect to SDN system or URTSI
2	Integration Port	RS232 – Connect to Lutron Intergration port
3	Power	3.5mm Barrel connector (female)








Integration with Lutron *LTI*



- PC based configuration software
- Connect PC to Translator with same USB to RS485 adapter as used for SDN motor configuration








Integration with Lutron *RTS*




RTS

Dry Contact control over RTS motors will require a QSE-IO board (Sold and distributed by Lutron) and a Dry Contact to RTS Interface. This solution will work with the following Lutron System(s):

- Homeworks QS
- Grafik Eye QS
- myRoom











Integration with Lutron *RTS*



RTS

Serial control over RTS motors will require an IP to RS-232 interface Digi One Converter (Sold and distributed by Lutron) and a Universal RTS Interface. This will require the Lutron Integrator to write custom command strings to the

URTSI. This solution will work with the following Lutron System(s):

Homeworks QS









Integration with Lutron *RTS*



RTS

Direct Control using the Somfy Connect LTI. Radio RA Main Repeater will be installed into the project. This now requires 2 interfaces from Somfy. The Somfy Connect LTI & a Universal RTS Interface (URTSI). This also requires a completed Lutron system to be functional to Program.

• Radio RA 2











Integration with Lutron



SDN

For Integration with the Somfy Digital Network, a Somfy Connect Universal Automation Interface Plus (UAI Plus) is required. The UAI Plus will have the ability to monitor the button presses from Lutron to send out Somfy Commands. There is no interface required from Lutron.

- Homeworks QS
- RadioRA 2
- RadioRA 2 Select
- Grafik Eye QS







Integration with Lutron *SDN*



SDN

For Integration with the Somfy Digital Network, where a UAI Plus is not present, The Somfy Connect LTI will be required. This connects into the RadioRA 2 Main Repeater and monitors the button presses.

RadioRA 2









Integration Training Presentation Thank you!



Like us on facebook <u>www.facebook.com/SomfyUS</u>



www.facebook.com/somfycanada



Follow us on Twitter @somfyus



www.linkedin.com/company/somfyus



www.instagram.com/somfyus/



www.pinterest.com/somfyus



1-800-22-SOMFY





Check us out on our YouTube channel, www.youtube.com/somfysystems

