



Zipscreen

INSTALLATION MANUAL

v5.4 | January 2025

 **SHADES BY MATISS**

New York | Chicago | Los Angeles

ZIPSCREEN®

CONTENTS

SECTION A TOOLS AND ADDITIONAL ITEMS REQUIRED	3
TOOLS REQUIRED	3
SECTION B PREPARATION	4
PRE-ASSEMBLED SHADE COMPONENTS	4
OPTIONAL ASSEMBLE SHADE ACCESSORIES	5
SECTION C INSTALLATION	6
MOUNTING ORIENTATION	6
BOX 120 / BOX 160 78MM TUBE	7
BOX 160 S100 TUBE	8
BOX 190 S100 TUBE	8
SPRING TENSION ADJUSTMENT	9
SHADE OPERATION	10
SIDE GUIDE INSTALLATION (FACE FIX ONLY)	11
SIDE GUIDE INSTALLATION U-MOUNTING RAIL	12
SIDE GUIDE INSTALLATION INNER RAIL	13
TEST OPERATION	15
BOX 120 / BOX 160 - INSTALL FRONT COVER	15
BOX 190 - INSTALL FRONT COVER	15
SECTION D OPERATION	16
ULTRA LOCK OPERATION	16
SECTION E ACCESSORIES	17
BOLT LOCK INSTALLATION	17
WALL MOUNTING CLIPS	17
SECTION F APPENDIX	18
MAX SPRING TURNS REFERENCE	18
REPLACE SPRING TENSIONER HEAD	19
MOTOR PROGRAMMING	20
SECTION G DOCUMENT CHANGE NOTES	23

DISCLAIMER

INTRODUCTION

This installation manual for Zipscreen System has been produced by Rollease Acmeda to supply the necessary information for the safe and correct installation of Zipscreen System.

DISCLAIMER

Rollease Acmeda has used reasonable care in preparing the information included in this document, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Rollease Acmeda assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Rollease Acmeda reserves the right to make changes without further notice to any products to improve reliability, function or design.

COPYRIGHT

COPYRIGHT © ROLLEASE ACMEDA

All rights are reserved. No part of this document may be reproduced or utilised in any means, by any means, electronic or mechanical including photocopying, recordings, or by any information storage or retrieval system, without the express permission from Rollease Acmeda.