General handling & Maintenance instructions metallized roller fabrics

Version 1.0 07.08.13



Production, Packaging, Delivery

- When possible assemble the products in an air conditioned environment.
- Storage; Please keep fabrics as long as possible in the delivered condition: in bubble foil, in the paper tube.
- Sweat, oil, grease etc. from labors can cause damage on the metallized side. Therefore please wear gloves during assembly of the product.
- Please avoid any handling which can damage on metalized and colored side of the fabric such as rubbing, sharp edges, pressing etc.
- Please use enough cushioning material such as air bubble and cardboard material to protect the product from rubbing, sharp edges, pressing etc.



Installation

- Please avoid installation of the products in high humidity areas such as bathrooms and kitchen.
- Please avoid direct contact by hand to the fabric. Or when needed wear gloves during installation
- Please avoid rubbing, sharp edges, pressing etc. on the metalized and colored side.



Maintenance and Handling

- Please roll up blind before opening the window.
- In case of manual chain system, please operate chain correctly (please avoid touching the fabric)
- Dust can be removed with a soft feather duster or by vacuum-cleaning with a soft brush at lowest position. When intensive cleaning is required, the colored side can be cleaned with a wet cloth. This wet cloth should not be too damp.
- In case of cleaning the window, please roll up the blind first to avoid any mist of window glass detergent coming on to the fabric.
- Please keep insects (like a fly mosquito etc.) away from the fabric.
- Please remove insect excrements as soon as possible from the fabric with a soft brush

