



SS38

INSTALLATION MANUAL



CONTENTS

SECTION A ITEMS REQUIRED	01
AVAILABLE IN US, AU, EU	01
AVAILABLE IN AU, EU ONLY	01
SECTION B INSTALLATION	02
INSTALLATION - LOW PROFILE MOUNTING CLIPS - US, AU, EU	02
INSTALLATION - SPRING LOADED MOUNTING CLIPS - AU, EU	04
SECTION C SHADE REMOVAL	06
SHADE REMOVAL - LOW PROFILE MOUNTING CLIPS	06
SHADE REMOVAL - SPRING LOADED MOUNTING CLIPS - AU, EU	07
SECTION D CORD REPLACEMENT	08
SLIM SPOOL	08
SECTION E TROUBLE SHOOTING	09

DISCLAIMER

INTRODUCTION

This Product Specifications manual for SS38 Systems has been produced by Rollease Acmeda to supply the necessary information for the safe and correct installation of SS38 Systems.

DISCLAIMER

Rollease Acmeda has used reasonable care in preparing the information included in this document, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Rollease Acmeda assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Rollease Acmeda reserves the right to make changes without further notice to any products to improve reliability, function or design.

COPYRIGHT

COPYRIGHT © ROLLEASE ACMEDA


All rights are reserved. No part of this document may be reproduced or utilised in any means, by any means, electronic or mechanical including photocopying, recordings, or by any information storage or retrieval system, without the express permission from Rollease Acmeda.



SECTION A | ITEMS REQUIRED

AVAILABLE IN US, AU, EU

SS38 - LOW PROFILE MOUNTING CLIPS




SYSTEM INDEX

1. Assembled SS38 Roman Shade
2. Low Profile Mounting Clips

AVAILABLE IN AU, EU ONLY

SS38 - SPRING LOADED MOUNTING BRACKETS




SYSTEM INDEX

1. Assembled SS38 Roman Shade
2. Spring Loaded Mounting Brackets [AU + EU only]



INSTALLATION - LOW PROFILE MOUNTING CLIPS - US, AU, EU


STEP 1. - ATTACH MOUNTING CLIPS TO WALL/CEILING



STEP 2. - ADJUST AS REQUIRED


Slight adjustment is available:

LOW PROFILE MOUNTING CLIP




STEP 3. - ENSURE STRAIGHT ALIGNMENT

Ensure mounting clips are in line





STEP 4. - INSTALLATION POSITIONING

For touch fabric appliaction: To make installation of the shade easier, lift the shade to the raised position & temporarily take the fabric off the head rail.






INSTALLATION - LOW PROFILE MOUNTING CLIPS**STEP 5. - ATTACH HEAD RAIL TO MOUNTING CLIPS**

Mount the shade assembly onto the Mounting Clips.



NOTE: Top Fix shown as example. Also applies to Face Fix.


STEP 6. - ATTACH HEAD RAIL TO MOUNTING CLIPS (COMPLETE)**STEP 7. - RE-ATTACH FABRIC FOR TOUCH FABRIC APPLICATION****STEP 8. - INSTALL CHAINHOLD TENSION DEVICE**

Cords on window coverings present a potential stragulation hazard. For Child Safety, Rollease Acmeda offers a range of Chainhold Tension Devices. The Chainhold Tension Device provides child safe tension mechanism for a chain roller system. Unless properly installed, the Chainhold Tension Device will partially prevent the window covering from functioning, making it fully compliant with the ANS/WCMA standard for safety.



INSTALLATION - SPRING LOADED MOUNTING BRACKETS - AU, EU


STEP 1. - ATTACH MOUNTING BRACKETS TO WALL/CEILING/HEAD BOARD



STEP 2. - ADJUST AS REQUIRED

Slight adjustment is available:


SPRING LOADED



FACE FIX
(cannot adjust top fix)


STEP 3. - ENSURE STRAIGHT ALIGNMENT

Ensure mounting clips are in line




STEP 4. - INSTALLATION POSITIONING

For touch fabric application: To make installation of the shade easier, lift the shade to the raised position & temporarily take the fabric off the head rail.




INSTALLATION - SPRING LOADED MOUNTING CLIPS - AU, EU**STEP 5. - ATTACH HEAD RAIL TO MOUNTING BRACKETS**


Mount the shade assembly onto the Mounting Brackets.




SAME FOR TOP
FIX & FACE FIX




NOTE: Top Fix shown as example. Also applies to Face Fix.

STEP 6. - ATTACH HEAD RAIL TO MOUNTING BRACKETS [COMPLETE]

TOP FIX



FACE FIX

STEP 7. - RE-ATTACH FABRIC FOR TOUCH FABRIC APPLICATION**STEP 8. - INSTALL CHAINHOLD TENSION DEVICE**

Cords on window coverings present a potential stragulation hazard. For Child Safety, Rollease Acmeda offers a range of Chainhold Tension Devices. The Chainhold Tension Device provides child safe tension mechanism for a chain roller system. Unless properly installed, the Chainhold Tension Device will partially prevent the window covering from functioning, making it fully compliant with the ANS/WCMA standard for safety.




SHADE REMOVAL - LOW PROFILE MOUNTING CLIPS

STEP 1. - DISENGAGE ORDER


Disengage clips at each end first

Disengage middle clip/s and remove shade




OPTION 1. - TOUCH TAPE APPLICATION

Remove fabric from head rail to access mounting clip




While bracket is flexing, apply force to twist extrusion off bracket




OPTION 2. - SPLINE APPLICATION

If fabric is splined, reach in behind shade to disengage brackets



SHADE REMOVAL - SPRING LOADED MOUNTING CLIPS - AU, EU


STEP 1. - REMOVE FABRIC FROM HEAD RAIL TO ACCESS MOUNTING CLIPS



STEP 2. - DISENGAGE ORDER


Disengage clips at each end first

Disengage middle clip/s and remove shade



STEP 3. - DISENGAGE BRACKETS



Press the center plastic release of mounting clip with finger to disengage from head rail





SLIM SPOOL

STEP 1. - REMOVE DAMAGED CORD FROM GUIDE


Remove damaged cord from spool cord guide and pull out notch




STEP 2. - ENSURE CORD NOTCH IS VISIBLE



STEP 3. - TIE A KNOT AT THE END OF CORD, INSERT INTO NOTCH & PULL



STEP 4. - RUN CORD INTO GUIDE & PULL UP



PROBLEM	CAUSE	SOLUTION
Uneven shade	Cord not running straight down	Make sure cord outlet of spool is aligned with cord clips on battens
	Cord in spool not aligned to start with	Make sure cords on every spool are aligned horizontally to ensure they wind down evenly
	Cord knots are uneven	Ensure the cord knots tied off at the bottom are even lengths and sit level and tight against the last batten
	Cord has overlapped in spool	Check the cord is spooling evenly along when wound. If the cord has overlapped itself, bring the shade all the way down then back up again to reset the cord
Cord loops seen below fabric	Cords are too long	Ensure the cord knots tied off at the bottom are even lengths and sit level and tight against the last batten
Noisy operation	Spool spacing is too great	Make sure you have enough spool across the length of the shade. This will stop any possible sagging between spools
	Spool not secure	Ensure all the spools are secured tightly to the head rail
	Rod deformed	Ensure the rod is straight and not deformed

